

AMWELD LOCATIONS.xls

4 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	4	7'8"	7 1/2	31 7/16	55 3/8	79 5/16	40 5/16
4.50	4	7'10"	7 1/2	32 13/16	58 1/8	83 7/16	40 5/16
4.50	4	8'	7 1/2	32 13/16	58 1/8	83 7/16	40 5/16
4.50	4	8'2"	7 1/2	32 13/16	58 1/8	83 7/16	40 5/16
4.50	4	8'4"	7 1/2	34 7/16	61 3/8	88 5/16	40 5/16
4.50	4	8'6"	7 1/2	34 7/16	61 3/8	88 5/16	40 5/16
4.50	4	8'8"	7 1/2	35 13/16	64 1/8	92 7/16	40 5/16
4.50	4	8'10"	7 1/2	35 13/16	64 1/8	92 7/16	40 5/16
4.50	4	9'	7 1/2	37 7/16	67 3/8	97 5/16	40 5/16
4.50	4	9'2"	7 1/2	37 7/16	67 3/8	97 5/16	40 5/16
4.50	4	9'4"	7 1/2	37 7/16	67 3/8	97 5/16	40 5/16
4.50	4	9'6"	7 1/2	38 13/16	70 1/8	101 7/16	40 5/16
4.50	4	9'8"	7 1/2	38 13/16	70 1/8	101 7/16	40 5/16
4.50	4	9'10	7 1/2	40 7/16	73 3/8	106 5/16	40 5/16
4.50	4	10'	7 1/2	40 7/16	73 3/8	106 5/16	40 5/16
5	4	7'8"	7 1/4	31 3/16	55 1/8	79 1/16	40 5/16
5	4	7'10"	7 1/4	32 9/16	57 7/8	83 3/16	40 5/16
5	4	8'	7 1/4	32 9/16	57 7/8	83 3/16	40 5/16
5	4	8'2"	7 1/4	32 9/16	57 7/8	83 3/16	40 5/16
5	4	8'4"	7 1/4	34 3/16	61 1/8	88 1/16	40 5/16
5	4	8'6"	7 1/4	34 3/16	61 1/8	88 1/16	40 5/16
5	4	8'8"	7 1/4	35 9/16	63 7/8	92 3/16	40 5/16
5	4	8'10"	7 1/4	35 9/16	63 7/8	92 3/16	40 5/16
5	4	9'	7 1/4	37 3/16	67 1/8	97 1/16	40 5/16
5	4	9'2"	7 1/4	37 3/16	67 1/8	97 1/16	40 5/16
5	4	9'4"	7 1/4	37 3/16	67 1/8	97 1/16	40 5/16
5	4	9'6"	7 1/4	38 9/16	69 7/8	101 3/16	40 5/16
5	4	9'8"	7 1/4	38 9/16	69 7/8	101 3/16	40 5/16
5	4	9'10	7 1/4	40 3/16	73 1/8	106 1/16	40 5/16
5	4	10'	7 1/4	40 3/16	73 1/8	106 1/16	40 5/16

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.