

BENCHMARK LOCATIONS.xls

2 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
<b>4.50</b>	<b>2</b>	<b>4'</b>	<b>5</b>	<b>33 1/2</b>	<b>X</b>	<b>X</b>	<b>40 5/16</b>
4.50	2	4'2"	5	35 1/2	X	X	40 5/16
4.50	2	4'4"	5	37 1/2	X	X	40 5/16
4.50	2	4'6"	5	39 1/2	X	X	40 5/16
4.50	2	4'8"	5	41 1/2	X	X	40 5/16
4.50	2	4'10"	5	43 1/2	X	X	40 5/16
4.50	2	5'	5	45 1/2	X	X	40 5/16
4.50	2	5'2"	5	47 1/2	X	X	40 5/16
4.50	2	5'4"	5	49 1/2	X	X	40 5/16
4.50	2	5'6"	5	51 1/2	X	X	40 5/16
4.50	2	5'8"	5	53 1/2	X	X	40 5/16
4.50	2	5'10"	5	55 1/2	X	X	40 5/16
4.50	2	6'	5	57 1/2	X	X	40 5/16
4.50	2	6'2"	5	61	X	X	40 5/16
4.50	2	6'4"	5	61	X	X	40 5/16
4.50	2	6'6"	5	61	X	X	40 5/16
4.50	2	6'8"	5	65 1/2	X	X	40 5/16
4.50	2	6'10"	5	65 1/2	X	X	40 5/16
4.50	2	7'	5	69 1/2	X	X	40 5/16
4.50	2	7'2"	5	69 1/2	X	X	40 5/16
<b>5</b>	<b>2</b>	<b>4'</b>	<b>4 3/4</b>	<b>33 1/4</b>	<b>X</b>	<b>X</b>	<b>40 5/16</b>
5	2	4'2"	4 3/4	35 1/4	X	X	40 5/16
5	2	4'4"	4 3/4	37 1/4	X	X	40 5/16
5	2	4'6"	4 3/4	39.25	X	X	40 5/16
5	2	4'8"	4 3/4	41.25	X	X	40 5/16
5	2	4'10"	4 3/4	43.25	X	X	40 5/16
5	2	5'	4 3/4	45.25	X	X	40 5/16
5	2	5'2"	4 3/4	47.25	X	X	40 5/16
5	2	5'4"	4 3/4	49.25	X	X	40 5/16
5	2	5'6"	4 3/4	51.25	X	X	40 5/16
5	2	5'8"	4 3/4	53.25	X	X	40 5/16
5	2	5'10"	4 3/4	55.25	X	X	40 5/16
5	2	6'	4 3/4	57.25	X	X	40 5/16
5	2	6'2"	4 3/4	60.75	X	X	40 5/16
5	2	6'4"	4 3/4	60.75	X	X	40 5/16
5	2	6'6"	4 3/4	60.75	X	X	40 5/16

Note: (1) Locations and adjustments must be verified with each manufacturer.

BENCHMARK LOCATIONS.xls

2 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
5	2	6'8"	4 3/4	65.25	X	X	40 5/16
5	2	6'10"	4 3/4	65.25	X	X	40 5/16
5	2	7'	4 3/4	69.25	X	X	40 5/16
5	2	7'2"	4 3/4	69.25	X	X	40 5/16

**Subtract clearance from hinge locations & undercut from strike locations for doors**

Note: (1) Locations and adjustments must be verified with each manufacturer.  
(2) HMF Express is not responsible for errors resulting from using this table.