

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	4	6'8"	7 1/2	24 1/16	43 1/2	67 3/8	36 5/8
4.50	4	7'	7 1/2	28 1/16	47 1/2	71 3/8	36 5/8
4.50	4	7'2"	7 1/2	30 1/16	49 1/2	73 3/8	36 5/8
5	4	6'8"	7 1/4	23 13/16	43 1/4	67 1/8	36 5/8
5	4	7'	7 1/4	27 13/16	47 1/4	71 1/8	36 5/8
5	4	7'2"	7 1/4	29 13/16	49 1/4	73 1/8	36 5/8

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.