

MESKER LOCATIONS.xls

3 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	3	5'	5	25 1/4	45 1/2	X	40 5/16
4.50	3	5'2"	5	26 1/4	47 1/2	X	40 5/16
4.50	3	5'4"	5	27 1/4	49 1/2	X	40 5/16
4.50	3	5'6"	5	28 1/4	51 1/2	X	40 5/16
4.50	3	5'8"	5	29 1/4	53 1/2	X	40 5/16
4.50	3	5'10"	5	30 1/4	55 1/2	X	40 5/16
4.50	3	6'	5	31 1/4	57 1/2	X	40 5/16
4.50	3	6'2"	5	32 1/4	59 1/2	X	40 5/16
4.50	3	6'4"	5	33 1/4	61 1/2	X	40 5/16
4.50	3	6'6"	5	34 1/4	63 1/2	X	40 5/16
4.50	3	6'8"	5	35 1/4	65 1/2	X	40 5/16
4.50	3	6'10"	5	36 1/4	67 1/2	X	40 5/16
4.50	3	7'	5	37 1/4	69 1/2	X	40 5/16
4.50	3	7'2"	5	38 1/4	71 1/2	X	40 5/16
4.50	3	7'4"	5	39 1/4	73 1/2	X	40 5/16
4.50	3	7'6"	5	40 1/4	75 1/2	X	40 5/16
4.50	3	7'8"	5	41 1/4	77 1/2	X	40 5/16
4.50	3	7'10"	5	42 1/4	79 1/2	X	40 5/16
4.50	3	8'	5	43 1/4	81 1/2	X	40 5/16
4.50	3	8'2"	5	44 1/4	83 1/2	X	40 5/16
4.50	3	8'4"	5	45 1/4	85 1/2	X	40 5/16
4.50	3	8'6"	5	46 1/4	87 1/2	X	40 5/16
4.50	3	8'8"	5	47 1/4	89 1/2	X	40 5/16
4.50	3	8'10"	5	48 1/4	91 1/2	X	40 5/16
4.50	3	9'	5	49 1/4	93 1/2	X	40 5/16
4.50	3	9'2"	5	50 1/4	95 1/2	X	40 5/16
4.50	3	9'4"	5	51 1/4	97 1/2	X	40 5/16
4.50	3	9'6"	5	52 1/4	99 1/2	X	40 5/16
4.50	3	9'8"	5	53 1/4	101 1/2	X	40 5/16
4.50	3	9'10"	5	54 1/4	103 1/2	X	40 5/16
4.50	3	10'	5	55 1/4	105 1/2	X	40 5/16
5	3	5'	4.75	25	45 1/4	X	40 5/16
5	3	5'2"	4.75	26	47 1/4	X	40 5/16
5	3	5'4"	4.75	27	49 1/4	X	40 5/16
5	3	5'6"	4.75	28	51 1/4	X	40 5/16
5	3	5'8"	4.75	29	53 1/4	X	40 5/16

Note: (1) Locations and adjustments must be verified with each manufacturer.

MESKER LOCATIONS.xls

3 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
5	3	5'10"	4.75	30	55 1/4	X	40 5/16
5	3	6'	4.75	31	57 1/4	X	40 5/16
5	3	6'2"	4.75	32	59 1/4	X	40 5/16
5	3	6'4"	4.75	33	61 1/4	X	40 5/16
5	3	6'6"	4.75	34	63 1/4	X	40 5/16
5	3	6'8"	4.75	35	65 1/4	X	40 5/16
5	3	6'10"	4.75	36	67 1/4	X	40 5/16
5	3	7'	4.75	37	69 1/4	X	40 5/16
5	3	7'2"	4.75	38	71 1/4	X	40 5/16
5	3	7'4"	4.75	39	73 1/4	X	40 5/16
5	3	7'6"	4.75	40	75 1/4	X	40 5/16
5	3	7'8"	4.75	41	77 1/4	X	40 5/16
5	3	7'10"	4.75	42	79 1/4	X	40 5/16
5	3	8'	4.75	43	81 1/4	X	40 5/16
5	3	8'2"	4.75	44	83 1/4	X	40 5/16
5	3	8'4"	4.75	45	85 1/4	X	40 5/16
5	3	8'6"	4.75	46	87 1/4	X	40 5/16
5	3	8'8"	4.75	47	89 1/4	X	40 5/16
5	3	8'10"	4.75	48	91 1/4	X	40 5/16
5	3	9'	4.75	49	93 1/4	X	40 5/16
5	3	9'2"	4.75	50	95 1/4	X	40 5/16
5	3	9'4"	4.75	51	97 1/4	X	40 5/16
5	3	9'6"	4.75	52	99 1/4	X	40 5/16
5	3	9'8"	4.75	53	101 1/4	X	40 5/16
5	3	9'10"	4.75	54	103 1/4	X	40 5/16
5	3	10'	4.75	55	105 1/4	X	40 5/16

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.