

FENESTRA LOCATIONS.xls

4 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	4	7'	5 1/4	27 1/4	49 1/4	71 1/4	40 5/16
4.50	4	7'1"	5 1/4	27 1/4	49 1/4	71 1/4	40 5/16
4.50	4	7'2"	5 1/4	27 1/4	49 1/4	71 1/4	40 5/16
4.50	4	7'3"	5 1/4	28 1/4	51 1/4	74 1/4	40 5/16
4.50	4	7'4"	5 1/4	28 1/4	51 1/4	74 1/4	40 5/16
4.50	4	7'5"	5 1/4	28 1/4	51 1/4	74 1/4	40 5/16
4.50	4	7'6"	5 1/4	29 1/4	53 1/4	77 1/4	40 5/16
4.50	4	7'7"	5 1/4	29 1/4	53 1/4	77 1/4	40 5/16
4.50	4	7'8"	5 1/4	29 1/4	53 1/4	77 1/4	40 5/16
4.50	4	7'9"	5 1/4	29 1/4	53 1/4	77 1/4	40 5/16
4.50	4	7'10"	5 1/4	30 9/16	55 7/8	81 1/4	40 5/16
4.50	4	7'11"	5 1/4	30 9/16	55 7/8	81 1/4	40 5/16
4.50	4	8'	5 1/4	30 9/16	55 7/8	81 1/4	40 5/16
4.50	4	8'1"	5 1/4	31 9/16	57 7/8	84 1/4	40 5/16
4.50	4	8'2"	5 1/4	31 9/16	57 7/8	84 1/4	40 5/16
4.50	4	8'3"	5 1/4	31 9/16	57 7/8	84 1/4	40 5/16
4.50	4	8'4"	5 1/4	32 9/16	59 7/8	87 1/4	40 5/16
4.50	4	8'5"	5 1/4	32 9/16	59 7/8	87 1/4	40 5/16
4.50	4	8'6"	5 1/4	32 9/16	59 7/8	87 1/4	40 5/16
4.50	4	8'7"	5 1/4	33 9/16	61 7/8	90 1/4	40 5/16
4.50	4	8'8"	5 1/4	33 9/16	61 7/8	90 1/4	40 5/16
4.50	4	8'9"	5 1/4	33 9/16	61 7/8	90 1/4	40 5/16
4.50	4	8'10"	5 1/4	34 9/16	63 7/8	93 1/4	40 5/16
4.50	4	8'11"	5 1/4	34 9/16	63 7/8	93 1/4	40 5/16
4.50	4	9'	5 1/4	34 9/16	63 7/8	93 1/4	40 5/16
4.50	4	9'1"	5 1/4	35 9/16	65 7/8	96 1/4	40 5/16
4.50	4	9'2"	5 1/4	35 9/16	65 7/8	96 1/4	40 5/16
4.50	4	9'3"	5 1/4	35 9/16	65 7/8	96 1/4	40 5/16
4.50	4	9'4"	5 1/4	36 9/16	67 7/8	99 1/4	40 5/16
4.50	4	9'5"	5 1/4	36 9/16	67 7/8	99 1/4	40 5/16
4.50	4	9'6"	5 1/4	36 9/16	67 7/8	99 1/4	40 5/16
4.50	4	9'7"	5 1/4	37 9/16	69 7/8	102 1/4	40 5/16
4.50	4	9'8"	5 1/4	37 9/16	69 7/8	102 1/4	40 5/16
4.50	4	9'9"	5 1/4	37 9/16	69 7/8	102 1/4	40 5/16
4.50	4	9'10"	5 1/4	38 9/16	71 7/8	105 1/4	40 5/16
4.50	4	9'11"	5 1/4	38 9/16	71 7/8	105 1/4	40 5/16

Note: (1) Locations and adjustments must be verified with each manufacturer.

FENESTRA LOCATIONS.xls

4 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	4	12'	5 1/4	34 9/16	71 7/8	105 1/4	40 5/16
5	4	7'	5	27	49	71	40 5/16
5	4	7'1"	5	27	49	71	40 5/16
5	4	7'2"	5	27	49	71	40 5/16
5	4	7'3"	5	28	51	74	40 5/16
5	4	7'4"	5	28	51	74	40 5/16
5	4	7'5"	5	28	51	74	40 5/16
5	4	7'6"	5	29	53	77	40 5/16
5	4	7'7"	5	29	53	77	40 5/16
5	4	7'8"	5	29	53	77	40 5/16
5	4	7'9"	5	29	53	77	40 5/16
5	4	7'10"	5	30 5/16	55 5/8	81	40 5/16
5	4	7'11"	5	30 5/16	55 5/8	81	40 5/16
5	4	8'	5	30 5/16	55 5/8	81	40 5/16
5	4	8'1"	5	31 5/16	57 5/8	84	40 5/16
5	4	8'2"	5	31 5/16	57 5/8	84	40 5/16
5	4	8'3"	5	31 5/16	57 5/8	84	40 5/16
5	4	8'4"	5	32 5/16	59 5/8	87	40 5/16
5	4	8'5"	5	32 5/16	59 5/8	87	40 5/16
5	4	8'6"	5	32 5/16	59 5/8	87	40 5/16
5	4	8'7"	5	33 5/16	61 5/8	90	40 5/16
5	4	8'8"	5	33 5/16	61 5/8	90	40 5/16
5	4	8'9"	5	33 5/16	61 5/8	90	40 5/16
5	4	8'10"	5	34 5/16	63 5/8	93	40 5/16
5	4	8'11"	5	34 5/16	63 5/8	93	40 5/16
5	4	9'	5	34 5/16	63 5/8	93	40 5/16
5	4	9'1"	5	35 5/16	65 5/8	96	40 5/16
5	4	9'2"	5	35 5/16	65 5/8	96	40 5/16
5	4	9'3"	5	35 5/16	65 5/8	96	40 5/16
5	4	9'4"	5	36 5/16	67 5/8	99	40 5/16
5	4	9'5"	5	36 5/16	67 5/8	99	40 5/16
5	4	9'6"	5	36 5/16	67 5/8	99	40 5/16
5	4	9'7"	5	37 5/16	69 5/8	102	40 5/16
5	4	9'8"	5	37 5/16	69 5/8	102	40 5/16
5	4	9'9"	5	37 5/16	69 5/8	102	40 5/16
5	4	9'10"	5	38 5/16	71 5/8	105	40 5/16

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.

FENESTRA LOCATIONS.xls

4 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
5	4	9'11"	5	38 5/16	71 5/8	105	40 5/16
5	4	12'	5	38 5/16	71 5/8	105	40 5/16

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.