

FIREDOOR LOCATIONS.xls

4 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.5 & 5	4	7'	5	26 1/2	48	69 1/2	38
4.5 & 5	4	7'2"	5	27 3/16	49 5/16	71 1/2	38
4.5 & 5	4	7'4"	5	27 13/16	50 11/16	73 1/2	38
4.5 & 5	4	7'6"	5	28 1/2	52	75 1/2	38
4.5 & 5	4	7'8"	5	29 3/16	53 5/16	77 1/2	38
4.5 & 5	4	7'10"	5	29 13/16	54 11/16	79 1/2	38
4.5 & 5	4	8'	5	30 1/2	56	81 1/2	38
4.5 & 5	4	8'2"	5	31 3/16	57 5/16	83 1/2	38
4.5 & 5	4	8'4"	5	31 13/16	58 11/16	85 1/2	38
4.5 & 5	4	8'6"	5	32 1/2	60	87 1/2	38
4.5 & 5	4	8'8"	5	33 3/16	61 5/16	89 1/2	38
4.5 & 5	4	8'10"	5	33 13/16	62 11/16	91 1/2	38
4.5 & 5	4	9'	5	34 1/2	64	93 1/2	38
4.5 & 5	4	9'2"	5	35 3/16	65 5/16	95 1/2	38
4.5 & 5	4	9'4"	5	35 13/16	66 11/16	97 1/2	38
4.5 & 5	4	9'6"	5	36 1/2	68	99 1/2	38
4.5 & 5	4	9'8"	5	37 3/16	69 5/16	101 1/2	38
4.5 & 5	4	9'10"	5	37 13/16	70 11/16	103 1/2	38
4.5 & 5	4	10'	5	38 1/2	72	105 1/2	38

Note: (1) Locations and adjustments must be verified with each manufacturer.