

FLEMMING LOCATIONS.xls

4 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	4	6'8"	7 1/2	27 29/64	47 27/64	67 3/8	40 5/16
4.50	4	6'10"	7 1/2	28 1/8	48 3/4	69 3/8	40 5/16
4.50	4	7'	7 1/2	28 51/64	50 5/64	71 3/8	40 5/16
4.50	4	7'2"	7 1/2	29 29/64	51 27/64	73 3/8	40 5/16
4.50	4	7'4"	7 1/2	30 1/8	52 3/4	75 3/8	40 5/16
4.50	4	7'6"	7 1/2	30 51/64	54 5/64	77 3/8	40 5/16
4.50	4	7'8"	7 1/2	31 29/64	55 27/64	79 3/8	40 5/16
4.50	4	7'10"	7 1/2	32 1/8	56 3/4	81 3/8	40 5/16
4.50	4	8'	7 1/2	32 51/64	58 5/64	83 3/8	40 5/16
4.50	4	8'2"	7 1/2	33 29/64	59 27/64	85 3/8	40 5/16
4.50	4	8'4"	7 1/2	34 1/8	60 3/4	87 3/8	40 5/16
4.50	4	8'6"	7 1/2	34 51/64	62 5/64	89 3/8	40 5/16
4.50	4	8'8"	7 1/2	35 29/64	63 27/64	91 3/8	40 5/16
4.50	4	8'10"	7 1/2	36 1/8	64 3/4	93 3/8	40 5/16
4.50	4	9'	7 1/2	36 51/64	66 5/64	95 3/8	40 5/16
4.50	4	9'2"	7 1/2	37 29/64	67 27/64	97 3/8	40 5/16
4.50	4	9'4"	7 1/2	38 1/8	68 3/4	99 3/8	40 5/16
4.50	4	9'6"	7 1/2	38 51/64	70 5/64	101 3/8	40 5/16
4.50	4	9'8"	7 1/2	39 29/64	71 27/64	103 3/8	40 5/16
4.50	4	9'10"	7 1/2	40 1/8	72 3/4	105 3/8	40 5/16
4.50	4	10'	7 1/2	40 10/13	74 5/64	107 3/8	40 5/16
5	4	6'8"	7 1/4	27 13/64	47 11/64	67 1/8	40 5/16
5	4	6'10"	7 1/4	27 7/8	48 1/2	69 1/8	40 5/16
5	4	7'	7 1/4	28 35/64	49 53/64	71 1/8	40 5/16
5	4	7'2"	7 1/4	29 13/64	51 11/64	73 1/8	40 5/16
5	4	7'4"	7 1/4	29 7/8	52 1/2	75 1/8	40 5/16
5	4	7'6"	7 1/4	30 35/64	53 53/64	77 1/8	40 5/16
5	4	7'8"	7 1/4	31 13/64	55 11/64	79 1/8	40 5/16
5	4	7'10"	7 1/4	31 7/8	56 1/2	81 1/8	40 5/16
5	4	8'	7 1/4	32 35/64	57 53/64	83 1/8	40 5/16
5	4	8'2"	7 1/4	33 13/64	59 11/64	85 1/8	40 5/16
5	4	8'4"	7 1/4	33 7/8	60 1/2	87 1/8	40 5/16
5	4	8'6"	7 1/4	34 35/64	61 53/64	89 1/8	40 5/16
5	4	8'8"	7 1/4	35 13/64	63 11/64	91 1/8	40 5/16
5	4	8'10"	7 1/4	35 7/8	64 1/2	93 1/8	40 5/16
5	4	9'	7 1/4	36 35/64	65 53/64	95 1/8	40 5/16

Note: (1) Locations and adjustments must be verified with each manufacturer.

4 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
5	4	9'2"	7 1/4	37 13/64	67 11/64	97 1/8	40 5/16
5	4	9'4"	7 1/4	37 7/8	68 1/2	99 1/8	40 5/16
5	4	9'6"	7 1/4	38 35/64	69 53/64	101 1/8	40 5/16
5	4	9'8"	7 1/4	39 13/64	71 11/64	103 1/8	40 5/16
5	4	9'10"	7 1/4	39 7/8	72 1/2	105 1/8	40 5/16
5	4	10'	7 1/4	40 35/64	73 53/64	107 1/8	40 5/16

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.