

AMWELD LOCATIONS.xls
3 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	3	5'	7 1/2	27 7/16	47 3/8	X	40 5/16
4.50	3	5'1"	7 1/2	27 15/16	48 3/8	X	40 5/16
4.50	3	5'2"	7 1/2	28 7/16	49 3/8	X	40 5/16
4.50	3	5'3"	7 1/2	28 15/16	50 3/8	X	40 5/16
4.50	3	5'4"	7 1/2	29 7/16	51 3/8	X	40 5/16
4.50	3	5'5"	7 1/2	29 15/16	52 3/8	X	40 5/16
4.50	3	5'6"	7 1/2	30 7/16	53 3/8	X	40 5/16
4.50	3	5'7"	7 1/2	30 15/16	54 3/8	X	40 5/16
4.50	3	5'8"	7 1/2	31 7/16	55 3/8	X	40 5/16
4.50	3	5'9"	7 1/2	31 15/16	56 3/8	X	40 5/16
4.50	3	5'10"	7 1/2	32 7/16	57 3/8	X	40 5/16
4.50	3	5'11"	7 1/2	32 15/16	58 3/8	X	40 5/16
4.50	3	6'	7 1/2	33 7/16	59 3/8	X	40 5/16
4.50	3	6'1"	7 1/2	33 15/16	60 3/8	X	40 5/16
4.50	3	6'2"	7 1/2	34 7/16	61 3/8	X	40 5/16
4.50	3	6'3"	7 1/2	34 15/16	62 3/8	X	40 5/16
4.50	3	6'4"	7 1/2	35 7/16	63 3/8	X	40 5/16
4.50	3	6'5"	7 1/2	35 15/16	64 3/8	X	40 5/16
4.50	3	6'6"	7 1/2	37 7/16	67 3/8	X	40 5/16
4.50	3	6'7"	7 1/2	37 7/16	67 3/8	X	40 5/16
4.50	3	6'8"	7 1/2	37 7/16	67 3/8	X	40 5/16
4.50	3	6'9"	7 1/2	37 7/16	67 3/8	X	40 5/16
4.50	3	6'10"	7 1/2	39 7/16	71 3/8	X	40 5/16
4.50	3	6'11"	7 1/2	39 7/16	71 3/8	X	40 5/16
4.50	3	7'	7 1/2	39 7/16	71 3/8	X	40 5/16
4.50	3	7'1"	7 1/2	39 7/16	71 3/8	X	40 5/16
4.50	3	7'2"	7 1/2	39 7/16	71 3/8	X	40 5/16
4.50	3	7'3"	7 1/2	41 7/16	75 3/8	X	40 5/16
4.50	3	7'4"	7 1/2	41 7/16	75 3/8	X	40 5/16
4.50	3	7'5"	7 1/2	41 7/16	75 3/8	X	40 5/16
4.50	3	7'6"	7 1/2	41 7/16	75 3/8	X	40 5/16
5	3	5'	7 1/4	27 3/16	47 1/8	X	40 5/16
5	3	5'1"	7 1/4	27 11/16	48 1/8	X	40 5/16
5	3	5'2"	7 1/4	28 3/16	49 1/8	X	40 5/16
5	3	5'3"	7 1/4	28 11/16	50 1/8	X	40 5/16
5	3	5'4"	7 1/4	29 3/16	51 1/8	X	40 5/16

Note: (1) Locations and adjustments must be verified with each manufacturer.

3 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
5	3	5'5"	7 1/4	29 11/16	52 1/8	X	40 5/16
5	3	5'6"	7 1/4	30 3/16	53 1/8	X	40 5/16
5	3	5'7"	7 1/4	30 11/16	54 1/8	X	40 5/16
5	3	5'8"	7 1/4	31 3/16	55 1/8	X	40 5/16
5	3	5'9"	7 1/4	31 11/16	56 1/8	X	40 5/16
5	3	5'10"	7 1/4	32 3/16	57 1/8	X	40 5/16
5	3	5'11"	7 1/4	32 11/16	58 1/8	X	40 5/16
5	3	6'	7 1/4	33 3/16	59 1/8	X	40 5/16
5	3	6'1"	7 1/4	33 11/16	60 1/8	X	40 5/16
5	3	6'2"	7 1/4	34 3/16	61 1/8	X	40 5/16
5	3	6'3"	7 1/4	34 11/16	62 1/8	X	40 5/16
5	3	6'4"	7 1/4	35 3/16	63 1/8	X	40 5/16
5	3	6'5"	7 1/4	35 11/16	64 1/8	X	40 5/16
5	3	6'6"	7 1/4	37 5/16	67 3/8	X	40 5/16
5	3	6'7"	7 1/4	37 3/16	67 1/8	X	40 5/16
5	3	6'8"	7 1/4	37 3/16	67 1/8	X	40 5/16
5	3	6'9"	7 1/4	37 3/16	67 1/8	X	40 5/16
5	3	6'10"	7 1/4	39 3/16	71 1/8	X	40 5/16
5	3	6'11"	7 1/4	39 3/16	71 1/8	X	40 5/16
5	3	7'	7 1/4	39 3/16	71 1/8	X	40 5/16
5	3	7'1"	7 1/4	39 3/16	71 1/8	X	40 5/16
5	3	7'2"	7 1/4	39 3/16	71 1/8	X	40 5/16
5	3	7'3"	7 1/4	41 3/16	75 1/8	X	40 5/16
5	3	7'4"	7 1/4	41 3/16	75 1/8	X	40 5/16
5	3	7'5"	7 1/4	41 3/16	75 1/8	X	40 5/16
5	3	7'6"	7 1/4	41 3/16	75 1/8	X	40 5/16

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.