

2 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	2	3'	6 3/4	24 3/4	X	X	18
4.50	2	3'2"	6 3/4	26 3/4	X	X	19
4.50	2	3'4"	6 3/4	28 3/4	X	X	20
4.50	2	3'6"	6 3/4	30 3/4	X	X	21
4.50	2	3'8"	6 3/4	32 3/4	X	X	22
4.50	2	3'10"	6 3/4	34 3/4	X	X	23
4.50	2	4'	6 3/4	36 3/4	X	X	24
4.50	2	4'2"	6 3/4	38 3/4	X	X	25
4.50	2	4'4"	6 3/4	40 3/4	X	X	26
4.50	2	4'6"	6 3/4	42 3/4	X	X	27
4.50	2	4'8"	6 3/4	44 3/4	X	X	28
4.50	2	4'10"	6 3/4	46 3/4	X	X	29
4.50	2	5'	6 3/4	48 3/4	X	X	30
5	2	3'	6 1/2	24 1/2	X	X	18
5	2	3'2"	6 1/2	26 1/2	X	X	19
5	2	3'4"	6 1/2	28 1/2	X	X	20
5	2	3'6"	6 1/2	30 1/2	X	X	21
5	2	3'8"	6 1/2	32 1/2	X	X	22
5	2	3'10"	6 1/2	34 1/2	X	X	23
5	2	4'	6 1/2	36 1/2	X	X	24
5	2	4'2"	6 1/2	38 1/2	X	X	25
5	2	4'4"	6 1/2	40 1/2	X	X	26
5	2	4'6"	6 1/2	42 1/2	X	X	27
5	2	4'8"	6 1/2	44 1/2	X	X	28
5	2	4'10"	6 1/2	46 1/2	X	X	29
5	2	5'	6 1/2	48 1/2	X	X	30

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.