

CECO LOCATIONS.xls
3 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	3	5'	6 3/4	27 3/4	48 3/4	X	41 13/16
4.50	3	5'2"	6 3/4	28 3/4	50 3/4	X	41 13/16
4.50	3	5'4"	6 3/4	29 3/4	52 3/4	X	41 13/16
4.50	3	5'6"	6 3/4	30 3/4	54 3/4	X	41 13/16
4.50	3	5'8"	6 3/4	31 3/4	56 3/4	X	41 13/16
4.50	3	5'10"	6 3/4	32 3/4	58 3/4	X	41 13/16
4.50	3	6'	6 3/4	33 3/4	60 3/4	X	41 13/16
4.50	3	6'2"	6 3/4	34 3/4	62 3/4	X	41 13/16
4.50	3	6'4"	6 3/4	35 3/4	64 3/4	X	41 13/16
4.50	3	6'6"	6 3/4	36 3/4	66 3/4	X	41 13/16
4.50	3	6'8"	6 3/4	37 3/4	68 3/4	X	41 13/16
4.50	3	6'10"	6 3/4	38 3/4	70 3/4	X	41 13/16
4.50	3	7'	6 3/4	39 3/4	72 3/4	X	41 13/16
4.50	3	7'2"	6 3/4	40 3/4	74 3/4	X	41 13/16
4.50	3	7'4"	6 3/4	41 3/4	76 3/4	X	41 13/16
4.50	3	7'6"	6 3/4	42 3/4	78 3/4	X	41 13/16
4.50	3	7'8"	6 3/4	43 3/4	80 3/4	X	41 13/16
4.50	3	7'10"	6 3/4	44 3/4	82 3/4	X	41 13/16
4.50	3	8'	6 3/4	45 3/4	84 3/4	X	41 13/16
4.50	3	8'2"	6 3/4	46 3/4	86 3/4	X	41 13/16
4.50	3	8'4"	6 3/4	47 3/4	88 3/4	X	41 13/16
4.50	3	8'6"	6 3/4	48 3/4	90 3/4	X	41 13/16
4.50	3	8'8"	6 3/4	49 3/4	92 3/4	X	41 13/16
4.50	3	8'10"	6 3/4	50 3/4	94 3/4	X	41 13/16
4.50	3	9'	6 3/4	51 3/4	96 3/4	X	41 13/16
4.50	3	9'2"	6 3/4	52 3/4	98 3/4	X	41 13/16
4.50	3	9'4"	6 3/4	53 3/4	100 3/4	X	41 13/16
4.50	3	9'6"	6 3/4	54 3/4	102 3/4	X	41 13/16
4.50	3	9'8"	6 3/4	55 3/4	104 3/4	X	41 13/16
4.50	3	9'10"	6 3/4	56 3/4	106 3/4	X	41 13/16
4.50	3	10'	6 3/4	57 3/4	108 3/4	X	41 13/16
5	3	5'	6 1/2	27 1/2	48 1/2	X	41 13/16
5	3	5'2"	6 1/2	28 1/2	50 1/2	X	41 13/16
5	3	5'4"	6 1/2	29 1/2	52 1/2	X	41 13/16
5	3	5'6"	6 1/2	30 1/2	54 1/2	X	41 13/16
5	3	5'8"	6 1/2	31 1/2	56 1/2	X	41 13/16

Note: (1) Locations and adjustments must be verified with each manufacturer.

3 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
5	3	5'10"	6 1/2	32 1/2	58 1/2	X	41 13/16
5	3	6'	6 1/2	33 1/2	60 1/2	X	41 13/16
5	3	6'2"	6 1/2	34 1/2	62 1/2	X	41 13/16
5	3	6'4"	6 1/2	35 1/2	64 1/2	X	41 13/16
5	3	6'6"	6 1/2	36 1/2	66 1/2	X	41 13/16
5	3	6'8"	6 1/2	37 1/2	68 1/2	X	41 13/16
5	3	6'10"	6 1/2	38 1/2	70 1/2	X	41 13/16
5	3	7'	6 1/2	39 1/2	72 1/2	X	41 13/16
5	3	7'2"	6 1/2	40 1/2	74 1/2	X	41 13/16
5	3	7'4"	6 1/2	41 1/2	76 1/2	X	41 13/16
5	3	7'6"	6 1/2	42 1/2	78 1/2	X	41 13/16
5	3	7'8"	6 1/2	43 1/2	80 1/2	X	41 13/16
5	3	7'10"	6 1/2	44 1/2	82 1/2	X	41 13/16
5	3	8'	6 1/2	45 1/2	84 1/2	X	41 13/16
5	3	8'2"	6 1/2	46 1/2	86 1/2	X	41 13/16
5	3	8'4"	6 1/2	47 1/2	88 1/2	X	41 13/16
5	3	8'6"	6 1/2	48 1/2	90 1/2	X	41 13/16
5	3	8'8"	6 1/2	49 1/2	92 1/2	X	41 13/16
5	3	8'10"	6 1/2	50 1/2	94 1/2	X	41 13/16
5	3	9'	6 1/2	51 1/2	96 1/2	X	41 13/16
5	3	9'2"	6 1/2	52 1/2	98 1/2	X	41 13/16
5	3	9'4"	6 1/2	53 1/2	100 1/2	X	41 13/16
5	3	9'6"	6 1/2	54 1/2	102 1/2	X	41 13/16
5	3	9'8"	6 1/2	55 1/2	104 1/2	X	41 13/16
5	3	9'10"	6 1/2	56 1/2	106 1/2	X	41 13/16
5	3	10'	6 1/2	57 1/2	108 1/2	X	41 13/16

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.