

FENESTRA LOCATIONS.xls

2 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	2	3'	5 1/4	26 1/4	X	X	18
4.50	2	3'1"	5 1/4	27 1/4	X	X	18 1/2
4.50	2	3'2"	5 1/4	28 1/4	X	X	19
4.50	2	3'3"	5 1/4	29 1/4	X	X	19 1/2
4.50	2	3'4"	5 1/4	30 1/4	X	X	20
4.50	2	3'5"	5 1/4	31 1/4	X	X	20 1/2
4.50	2	3'6"	5 1/4	32 1/4	X	X	21
4.50	2	3'7"	5 1/4	33 1/4	X	X	21 1/2
4.50	2	3'8"	5 1/4	34 1/4	X	X	22
4.50	2	3'9"	5 1/4	35 1/4	X	X	22 1/2
4.50	2	3'10"	5 1/4	36 1/4	X	X	23
4.50	2	3'11"	5 1/4	37 1/4	X	X	23 1/2
4.50	2	4'	5 1/4	38 1/4	X	X	24
4.50	2	4'1"	5 1/4	39 1/4	X	X	24 1/2
4.50	2	4'2"	5 1/4	40 1/4	X	X	25
4.50	2	4'3"	5 1/4	41 1/4	X	X	25 1/2
4.50	2	4'4"	5 1/4	42 1/4	X	X	26
4.50	2	4'5"	5 1/4	43 1/4	X	X	26 1/2
4.50	2	4'6"	5 1/4	44 1/4	X	X	27
4.50	2	4'7"	5 1/4	45 1/4	X	X	27 1/2
4.50	2	4'8"	5 1/4	46 1/4	X	X	28
4.50	2	4'9"	5 1/4	47 1/4	X	X	28 1/2
4.50	2	4'10"	5 1/4	48 1/4	X	X	29
4.50	2	4'11"	5 1/4	49 1/4	X	X	29 1/2
5	2	3'	5	26	X	X	18
5	2	3'1"	5	27	X	X	18 1/2
5	2	3'2"	5	28	X	X	19
5	2	3'3"	5	29	X	X	19 1/2
5	2	3'4"	5	30	X	X	20
5	2	3'5"	5	31	X	X	20 1/2
5	2	3'6"	5	32	X	X	21
5	2	3'7"	5	33	X	X	21 1/2
5	2	3'8"	5	34	X	X	22
5	2	3'9"	5	35	X	X	22 1/2
5	2	3'10"	5	36	X	X	23
5	2	3'11"	5	37	X	X	23 1/2

Note: (1) Locations and adjustments must be verified with each manufacturer.

2 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
5	2	4'	5	38	X	X	24
5	2	4'1"	5	39	X	X	24 1/2
5	2	4'2"	5	40	X	X	25
5	2	4'3"	5	41	X	X	25 1/2
5	2	4'4"	5	42	X	X	26
5	2	4'5"	5	43	X	X	26 1/2
5	2	4'6"	5	44	X	X	27
5	2	4'7"	5	45	X	X	27 1/2
5	2	4'8"	5	46	X	X	28
5	2	4'9"	5	47	X	X	28 1/2
5	2	4'10"	5	48	X	X	29
5	2	4'11"	5	49	X	X	29 1/2

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.

(2) HMF Express is not responsible for errors resulting from using this table.