

2 HINGES

Hinge Size	Hinge Qty.	Opening Height	1st Hinge	2nd Hinge	3rd Hinge	4th Hinge	Strike Location AFF
4.50	2	3'	7 1/2	23 3/8	X	X	18
4.50	2	3'2"	7 1/2	25 3/8	X	X	19
4.50	2	3'4"	7 1/2	27 3/8	X	X	20
4.50	2	3'6"	7 1/2	29 3/8	X	X	21
4.50	2	3'8"	7 1/2	31 3/8	X	X	22
4.50	2	3'10"	7 1/2	33 3/8	X	X	23
4.50	2	4'	7 1/2	35 3/8	X	X	24
4.50	2	4'2"	7 1/2	37 3/8	X	X	25
4.50	2	4'4"	7 1/2	39 3/8	X	X	26
4.50	2	4'6"	7 1/2	41 3/8	X	X	27
4.50	2	4'8"	7 1/2	43 3/8	X	X	28
4.50	2	4'10"	7 1/2	45 3/8	X	X	29
4.50	2	5'	7 1/2	47 3/8	X	X	30
5	2	3'	7 1/4	23 1/8	X	X	18
5	2	3'2"	7 1/4	25 1/8	X	X	19
5	2	3'4"	7 1/4	27 1/8	X	X	20
5	2	3'6"	7 1/4	29 1/8	X	X	21
5	2	3'8"	7 1/4	31 1/8	X	X	22
5	2	3'10"	7 1/4	33 1/8	X	X	23
5	2	4'	7 1/4	35 1/8	X	X	24
5	2	4'2"	7 1/4	37 1/8	X	X	25
5	2	4'4"	7 1/4	39 1/8	X	X	26
5	2	4'6"	7 1/4	41 1/8	X	X	27
5	2	4'8"	7 1/4	43 1/8	X	X	28
5	2	4'10"	7 1/4	45 1/8	X	X	29
5	2	5'	7 1/4	47 1/8	X	X	30

Subtract clearance from hinge locations & undercut from strike locations for doors

Note: (1) Locations and adjustments must be verified with each manufacturer.